


## WEBER CARBURETTORS


32 ICEV

FIAT



Key No.	Qty.	Part Name	Part Number	Key No.	Qty.	Part Name	Part Number
1	1	Carburettor Cover—including	31706.026	19	1	Idle Jet Holder Gasket	41565.002
2	2	- Stud	64955.102	20	1	Idle Jet Holder	
3	5	Cover Fixing Screw	64700.005	21	1	Choke Lever Screw.	64700.012
4	1	Carburettor Cover Gasket	41700.008	22	1	Choke Lever Washer	55510.002
5	1	Filter Element	37022.004	23	1	Choke Lever Assembly - including	45202.047
6	1	Filter Housing Plug	61002.019	24	1	- Choke Lever	45202.048
7	1	Needle Valve Gasket	41535.015	25	1	- Cable Fixing Screw	64615.004
8	1	Needle Valve	79507.150*†	26	1	Choke Cable Bracket Screw	64700.012
9	2	Choke Plate Screw	64525.003	27	1	Choke Lever Spring	47610.056
10	1	Choke Operating Rod	61287.006	28	-1	Choke Cable Bracket Assembly - including	58702.019
11	1	Choke Shaft.	10015.224	29	1	- Cable Bracket	58700.023
12	1	Choke Plate	64010.023	30	1	- Clamp	52145:004
13	1	Float (Brass).	41020.001	31	4	- Clamp Screw	64615.007
13	1	Float (Plastic)	41020.002	32	1	Carburettor Base - including.	67006.003
14	1	Air Corrector Jet	77201 *	33	1.	- Base	Not Supplied
15	1	Emulsion Tube	81440. *	34	1	- Throttle Plate	64005.092
16	1	Main Jet	73801. *	35	2	- Throttle Plate Screw	64520.023
17	1	Carburettor Body	Not Supplied	36	1	- Shaft Return Spring	47610.076
18	1	Idle Jet	81002. *	37	1	- Throttle Shaft including	10015.225

No. Qt	/- Part Name	Part Number	Key No.	Qty.	Part Name	Part Number
38 1 1 339 1 40 2 41 1 1 42 1 43 1 444 1 1 45 1 46 1 47 1 1 48 1 1 50 1 1 55 3 1 1 55 4 1 1 56 6 1 1 57 2 2	- Fast Idle Speed Screw - Nut Carburettor Base Fixing Screw Spring for Idle Mixture Screw Mixture Screw Sealing Ring Idle Mixture Screw Throttle Stop Screw Spring for Throttle Stop Screw Pump Control Lever Locktab Nut Blanking Disc Blanking Disc Spring Insulating Flange Pump Rod Split Pin Pump Control Rod Pump Rod Spring Pump Diaphragm Pump Return Spring Pump Jet Gasket	34710.003 50002.005 47600.027 39152.006 32610.006 61285.014 47600.101 47407.042 †	58 59 60 61 62 63 64 65 66 67 68 89 70 71 72	1 1 1 1 1 1 1 2 2 1 1 1 2 2 2	Pump Jet Locknut Rod Adjustment Bush Pump Discharge Valve Float Fulcrum Pin Pull Down Rod Pull Down Rod Split Pin Auxiliary Venturi Pump Cover Screw — Long Pump Cover Screw — Short Pump Cover Pull Down Tube Pull Down Device Screw Pull Down Rod Washer *Calibrated Parts Gasket Kit. Tune Up Kit Master Repair Kit	34710.009* 12800.166 64290.015 † 52000.015 61280.079 32610.006 70507 64700.019 64700.004 32486.040 61400.009 57804.030 64700.012 55510.056



## (\*\*) DIRECTIONS FOR LEVELLING THE FLOAT

It is essential that the following directions be complied with in order to obtain correct levelling of the float:

- · Make sure that the needle valve (V) is tightly screwed in its housing.
- Keep the carburettor cover (C) in vertical position as shown in figure since the weight of the float (G could lower the ball (SF) fitted on the needle.
- With carburettor cover (C) in vertical position and float tab (LC) in light contact with the ball (SF) on the needle (S), the distance of float (G) from the surface of the cover, with gasket (GZ) fitted and adhering, must measure 11 mm for brass float and 36 mm for plastic float.
- After the levelling has been done check that the stroke of the float (G) is 7 mm for brass float and 8.5 mm for plastic float, if necessary adjust the position of the lug (A). Check that return hook (R) of the needle (S) allows it free movement in its seat.
- Should the float (G) be incorrectly positioned, bend the tongue (L) of the float until the required
  point is reached. Make sure that the float tab (LC) is perpendicular to the needle (S) and does not
  have any indentation on the contact surface which might affect the free movement of the needle
  itself.
- · Check that the float (G) can swing freely on its axis.

## Note

The operation of levelling the float must be carried out whenever it is necessary to replace needle valve (V) and it is advisable to ensure that it is correctly tightened onto a new seating gasket.

## WEBER CARBURETTORS CONCESSIONAIRES (U.K.) LTD.

Dolphin Road, Sunbury, Middlesex TW16 7HE Telephone Sunbury (0932) 788805 Telex 928636